



## STYLEQUEST MULTI-POSITION COILS

### STANDARD FEATURES

Multi-Position  
Up-flow horizontal right or  
Up-flow horizontal left  
Order your desired configuration.

Fully insulated embossed  
Galvanized cabinet  
Polymer drain pans (two)  
Dual drain connections on  
each drain pan  
Heavy copper tube with  
Aluminum fins  
Aluminum end plates are standard  
Cap-Flowrator refrigerant  
Metering

### OPTIONAL FEATURES

Thermal expansion valves  
Powder painted cabinet  
Heat pump application

Specify StyleQuest cabinet when  
ordering.  
Specify right or left drain and  
refrigerant

### CABINET DIMENTIONS

Cabinet Code	Coils 14 -16"	Coils 18 - 20"	Coils 22 - 24"	Coils 26-30"	Cabinet Height F	Cabinet Depth S	Opening Height W	Opening Width D
	Cabinet Length H							
Q5	21.25"	25.25"	28.75"	34.75"	14.50"	21.50"	13.25"	20.25"
Q5G	21.25"	25.25"	28.75"	34.75"	14.00"	21.50"	12.25"	20.25"
Q6	21.25"	25.25"	28.75"	34.75"	16.50"	21.50"	15.25"	20.25"
Q6G	21.25"	25.25"	28.75"	34.75"	17.50"	21.50"	15.75"	20.25"
Q6A	21.25"	25.25"	28.75"	34.75"	17.75"	21.50"	16.50"	20.25"
Q8	21.25"	25.25"	28.75"	34.75"	21.50"	21.50"	20.00"	20.25"
Q8G	21.25"	25.25"	28.75"	34.75"	21.00"	21.50"	19.25"	20.25"
Q8Y	21.25"	25.25"	28.75"	34.75"	22.25"	21.50"	21.00"	20.25"
Q8A	21.25"	25.25"	28.75"	34.75"	24.75"	21.50"	23.50"	20.25"
Q9G	21.25"	25.25"	28.75"	34.75"	24.50"	21.50"	22.75"	20.25"

Specifications can change without notice



## STYLEQUEST MULTI-POSITION COILS

### INSTALLATION INSTRUCTIONS

The StyleQuest coil is a multi-position coil for up-flow or horizontal use.

The coil is designed for either horizontal right or horizontal left applications, but not for both. Air should enter the base of the coil and not the apex. All StyleQuest coils will install in the up-flow position.

A drip shield must be installed on Stylequest coils which have a coil that is greater than 22" in length. Attach the supplied drip shield to the end of the drain pan at the discharge end of the coil. The coil must be installed in a level position.

**IT IS NOT RECOMMENDED THAT  
AIR ENTER THE APEX END OF  
THE COIL!**

A red arrow on the coil indicates correct airflow direction for horizontal installation.



### Ordering Instructions

Specify cabinet when ordering (ASQN24-A264□+D-**Q5** LH)

Specify left or right refrigeration and drain connections (ASQN24-A264□+D-Q5 **LH**)

Specify heat pump application when ordering by adding **P** in model number (ASQN**P**24-A264□+D-Q5 LH)